

E-Manage Blue Wiring Diagram - Toyota Celica '00-'02 M/T

	E-Manage		Toyota			Connection Type
	Name	Colour	Name	Plug-Pin	Colour	
<b>Main Harness</b>	B+	R	IGSW	E2-8	B-O	T
	E	B	E03	E2-7	W-B	T
	I	BR	TACH	E3-27	BR-W	T
	Th	GY	VTA	E4-23	B-W	T
	Ar	G	VG	E4-11	G-W	ECU
	Ar	W	VG	E4-11	G-W	ENG
<b>INJ Harness</b>	#E	B-R	E03	E2-7	W-B	T
	#1	BL-R	#10	E5-1	R	T
	#2	O-R	#30	E5-3	R-W	T
	#3	Y-R	#40	E5-4	R-BL	T
	#4	P-R	#20	E5-2	R-BL	T
<b>IGN Harness</b>	t1	BL-W	IGT1	E5-10	R-B	ECU
	t2	O-W	IGT3	E5-12	G-R	ECU
	t3	Y-W	IGT4	E5-13	R-Y	ECU
	t4	P-W	IGT2	E5-11	R-W	ECU
	t1	BL-B	IGT1	E5-10	R-B	ENG
	t2	O-B	IGT3	E5-12	G-R	ENG
	t3	Y-B	IGT4	E5-13	R-Y	ENG
	t4	P-B	IGT2	E5-11	R-W	ENG

COLOUR CODING AND ABBREVIATIONS

B = BLACK  
R = RED  
BR = BROWN  
G = GREEN  
Y = YELLOW  
BL = BLUE  
P = PINK  
O = ORANGE  
W = WHITE  
GY = GREY

T = Tap into wire

ECU = Cut Wire, attach Emanage wire to wire going to ECU

ENG = Cut Wire, attach Emanage wire to wire going to Engine